Instructions for wear checks of play equipment

Playground.....

Date of installation


Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.

Intervals for maintenance work and checks generally depend on

- the location
- the usage
- the frequency of use
- possible vandalism

For more details see also "General instructions for maintenance of playgrounds".

Prism Column Order No. 10.31200



The equipment must be checked for	
correct operation and safety, especially	
the points listed below:	

Check that prism sits firmly in the fixture.

Prism

2. Check the inside of the prism – must be free of condensation.

Stainless steel

3. Clean with stainless steel spray (www.kimtec.de) using a clean cloth.

Acrylic glass

4. If screens are soiled, clean using regular dishwashing liquid and a lint-free cloth; do **NOT** use spirits or turpentine!

Structural stability

- 5. Check anchoring to the ground once a year.
- Repair not carried out,
it is still possible to play on equipment
 Image: Constraint of the second s

..... Date

Maintenance carried out by:

Proof of

maintenance

everything is in order

Last updated: Aug. 01 2007 Richter Spielgeräte GmbH **INFORMATION SHEET for customers** applies to: liquid contained in Whirlpool Column and Water Prism NAME OF HAZARDOUS MATERIAL Special anti-freeze liquid (contains 25 % glycol) HAZARDS TO HUMAN HEALTH AND THE ENVIRONMENT Harmful if swallowed. Details hygroscopic incompatible with various synthetic materials esundheit schädlich Hazards to the environment: slightly hazardous to water (WGK 1, according to German water hazard class system) SAFETY MEASURES AND HANDLING Keep containers always closed. Do not spill or splash liquid when decanting or filling. Materials that can react must be kept away or added in a controlled manner. Avoid spraying. Do not eat, drink, smoke or breathe in through your nose. Avoid inhaling vapors or mists. Avoid eye and skin contact. Thoroughly clean hands and other contaminated parts of the body at the end of the working day and before every break. Use skin care products. Store leisure clothes separate from work clothes! Pay attention to work restrictions! Eye protection: Wear safety glasses with side protection. Hand protection: Wear gloves made of nitrile rubber. Coating thickness 0.11 mm. Breakthrough time: >480 min. Body protection: During filling: Wear protective apron! ACCIDENTAL RELEASE MEASURES Always wear protective glasses and gloves when cleaning up leaks or spills. Pick up and dispose of liquid using absorbent, noncombustible material (e. g. diatomaceous earth, sand)! Thoroughly ventilate the room afterwards. FIRST AID MEASURES General advice for first aid measures: Protect yourself. Provide basic life saving measures such as "recovery position" (lateral recumbent position), " cardiopulmonary resuscitation", "shock treatment" depending on the situation. Cover wounds with sterile dressing. Provide for physical rest and protect against thermal loss. Consult a doctor (eye specialist if necessarv) Eye exposure: while protecting the unhurt eye immediately and thoroughly rinse the other one using water (approx. 10 minutes) with eye lid open. In case of eye injury apply sterile bandage. After eye contact, ophthalmological treatment is mandatory Skin exposure: Immediately take off clothes, including underwear and shoes. Rinse skin with large amount of water. Inhalation: Remove injured person from exposure, always ensuring self-protection. If breathing is difficult, have injured inhale oxygen. In case of apnea, artificial respiration is necessary: use respiratory appliances. Ingestion: Immediately rinse mouth thoroughly. **DISPOSAL CONSIDERATIONS** Do not dispose into sink or garbage can! Collect waste separately. Product: Keep containers. Drain into designated containers only. For disposal, return containers to Richter Spielgeräte GmbH, Simsseestr. 29, 83112 Frasdorf, Germany. Disposal is free of charge.