Instructions for wear checks of play equipment	СО	The equipment must be checked for correct operation and safety, especially the points listed below:		Proof of maintenance	
	1. 2. 3.	wooden parts Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks. Check that all bolts and screws are tight and retighten if necessary. Recommendation: apply paraffin wax to the upper end grain areas once a year, please refer to Order No. 0.90100, 1 litre. Check the ash wood rungs of the ladder for wear and tear, the remaining diameter must be at least 30 mm. Structural stability	1		
1 4 2 5	Re	Slide 3.19210 Chain Path 3.66260 Climbing Trunk 3.69510 Note Please check that all documents are included!		Special notes, e.g. for repairs	
	Re	s still possible to play on equipment pair not carried out, uipment is taken out of action			
	All	work carried out, erything is in order			
or spare parts refer to back of page.	1	nintenance carried out by:Date			

Spare Parts Tower Combination 185 Order No. 2.18500/ L2.18500



Please note that the safety standards of the equipment must not be affected. Therefore, when carrying out repairs it is helpful to **only use original parts**.

Order No. Spare part

0.92630 ladder for tower without roof

5 rungs

0.98310 single rung

0.30070 tower cladding, length 2.30 m

spruce, impregnated

0.30080 tower cladding, length 2.30 m

larch

0.97283 ladder for platform hut

5 rungs

0.98350 single rung

For further spare parts please see spare parts list!