The equipment must be checked for Instructions for wear Proof of correct operation and safety, especially maintenance checks of play equipment the points listed below: Wooden parts Playground 1. Check for rot and, if necessary, smooth out Date of installation splinters and round off sharp edges of cracks. Checks depend on the type of equipment. Check that all bolts and screws are tight and Any equipment with moving parts must retighten if necessary; grind/cut off protruding be checked at least twice a year, static bolt ends, regalvanise with zinc spray. equipment at least once a year. Swing suspension Intervals for maintenance work and checks generally depend on Make sure that the joints move smoothly. - location 4. Make sure that the swivels move smoothly, - kind of use apply grease if required. - frequency of use - possible vandalism 5. Check welds of metal cross beam for cracks. For more details see also "General 6. Check chain and connection to chain; instructions for maintenance of the first chain link must be locked firmly in playgrounds". the swivel; check wear on contact surfaces between first and second chain link. Toddler's Twin Swing special **Belt seats** Order No. 6.12720/K6.12720 3 4 5 6 7. Check belt seats for vandalism (e.g. cuts) and replace if necessary 8. Check the seats for a minimum ground clearance of at least 30 cm. Structural stability 9. In order to check for rot at wooden parts or steel feet for corrosion, uncover the Special notes, e.g. for repairs foundations once a year. Repair not carried out, it is still possible to play on equipment Repair not carried out, equipment is taken out of action All work carried out, everything is in order Maintenance carried out by: For spare parts refer to back of page. Date

Spare Parts
Toddler's Twin
Swing special
Order No. 6.12720/K6.12720



Please note that the safety standards of the equipment must not be affected. Therefore, when carrying out repairs it is helpful to **only use original parts**.