

Instructions for wear checks of play equipment

The equipment must be checked for correct operation and safety, especially the points listed below:

Proof of maintenance

Playground.....

Date of installation


Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.

Intervals for maintenance work and checks generally depend on


- location
- usage
- frequency of use
- possible vandalism

For more details see also our general instructions for maintenance of playgrounds!

Curved Sand Chute Order No. 5.97090



Bottom Sand Chute Order No. 5.97060



Fixing

1. Check that the sand pipe is securely connected and retighten bolts/screws if necessary.
2. Check for wear and tear, replace if worn heavily.

Special notes, e.g. for repairs

Repair not carried out, it is still possible to play on equipment

Repair not carried out, equipment is taken out of action

All work carried out, everything is in order

Maintenance carried out by:


..... Date

Spare parts
Curved Sand Chute
Order No. 5.97090

Please note that the safety standards of the equipment must not be affected. Therefore, when carrying out repairs it is helpful to **only use original parts.**

Order No. Spare parts

0.97060 Bottom Sand Chute



0.97090 Curved Sand Chute

