For spare parts refer to back of page

nis copy may be copied for maintenance of Richter play equipment.				Page	
Instructions for wear checks of play equipment	со	The equipment must be checked for correct operation and safety, especially the points listed below:		Proof of maintenance	
Playground		Wooden parts			
Date of installation	1.	Check for rot and, if necessary, smooth out splinters and round off sharp edges of cracks.			
Checks depend on the type of equipment. Any equipment with moving parts must be checked at least twice a year, static equipment at least once a year.	2.	Check that all wood connections are tight and retighten if necessary. Grind /cut off protruding bolt ends. Regalvanise with zinc spray.			
Intervals for maintenance work and checks generally depend on		Swing suspension			
- location	3.	Make sure that the joints move smoothly.			
<ul><li>kind of use</li><li>frequency of use</li><li>possible vandalism</li></ul>	4.	Make sure that the swivels move smoothly, apply grease if required.			
For more details see also "General	5.	Check welds of steel cross beam for cracks.			
instructions for maintenance of playgrounds".  High Twin Swing special	6.	Check chains and connections to chains; the first chain link must be locked; check wear on contact surfaces between first and second chain link.			
Order No. 6.14020/K6.14020		Swing seats			
(2) (4) (5)	7.	Replace if metal parts are exposed.			
2 6	8.	Check the seats for a ground clearance of 40 cm.			
		Structural stability			
7 40 cm 8 9	9.	In order to check steel feet for corrosion, uncover the foundation once a year.		g. for repairs	
				Special notes, e.g. for repairs	
		Repair not carried out, it is still possible to play on equipment			
		pair not carried out, uipment is taken out of action			
		work carried out, erything is in order			
	Ma	intenance carried out by:	1		

Spare Parts High Twin Swing special Order No. 6.14020



Please note that the safety standards of the equipment must not be affected. Therefore, when carrying out repairs it is helpful to **only use original parts**.

		parts.	
Order No.	Spare part	Order No.	Spare part
0.93000	rubber swing seat	0.93090	U-shackle with swivel
0.93010	rubber swing seat with 4 eyebolts	0.88150	brass bush for swing joint
0.93020	rubber swing seat with 2 V-chains	0.20010	stainless steel machine bolt M8x55 with locking nut
0.93021	V-chain	0.20020	stainless steel machine bolt M8x28 with locking nut
0.93100	chains (pair) 6 mm length 2.35 m		
0.93110	rubber swing seat with chains		